



Austral Lock


Verta Offset Pull Handle Installation Instructions

Pack Contents:

1. 1 x Pull handle Set (preassembled)
2. 4 x Pressure Pads (preassembled)
3. 2 x 2mm Washer (preassembled)
4. 2 x Short fixing screws M5 x 58mm (preassembled)
5. 2 x Grub Screws (preassembled)
6. 2 x Long fixing screws M5 x 72mm (in kit)
7. 1 x Allen Key (in kit)
- 1 x Instruction Sheet (in kit)


Tools Required:

- Tape Measure
- Ø11mm Drill Bit
- Pencil
- Spirit Level
- Spanner



1. Door Preparation

- (a) With a pencil, mark the centre of the holes to be drilled (both sides of door).
Ensure to allow for correct backset when installing with a mortise lock.
- (b) Check alignment using a spirit level.
- (c) Drill Ø11 mm holes, both sides.
- (d) When installed with a mortice sliding door lock, (not included), align handle bottom hole with the hole through lock




2. Outside Handle Installation

- (a) Fit the screw and the washer as shown.

NOTE: Use short set for door thickness up to 40 mm.


Use long set for door thickness up to 55 mm.

- (b) Place outside handle onto extrusion with the studs in the drilled holes.
- (c) Secure from inside.



3. Inside Handle Installation

- (a) Ensure grub screws are fitted both ends of the inside handle without protruding in the main cavity.
- (b) Position inside handle over the hex heads of the fixing screws on both ends and push until it is flush with door surface.
- (c) Tighten grub screws using the Allen Key.



Cleaning and Maintenance

Although stainless steel is very resistant to corrosion, factors exist which cause stainless steel to stain or discolour, impairing the overall look. This brown discolouration, also known as tea staining, does not affect the structural integrity or the longevity of the material and it can be controlled.

Any discolouration should be removed immediately or permanent discolouration and pitting of the surface could occur. In most cases, if attended to immediately, the product can be restored to its original condition.

The following are recommendations to prevent and/or remove discolouration:

- **Wash Regularly** – In coastal or caustic environments stainless steel finishes may tea stain if not washed regularly to remove salt. Cleaning involves washing with a potable, low chloride water or washing with a neutral detergent followed by rinsing with potable water. If products are not regularly washed, pits may develop and the surface may be permanently damaged.

- **Cleaning** – Most discolouration can be removed with a mild cleanser (Ajax, Detol, Sugar Soap etc.) or a specialist stainless steel cleanser (3M Stainless Steel Cleanser, Goddard's Stainless Steel Cleaner, Revere Ware Stainless Steel Cleanser etc.) and a non scratch cleaning sponge or cloth.

- Apply potable clean water with the cleaning sponge and rub gently. If the mark does not shift, apply the specialist stainless steel cleanser and rub gently. An old toothbrush can be used to get into any difficult areas. The surface should then be thoroughly rinsed with potable clean water and buffed with a soft cloth.

NEVER rub across the grain as the finish may be spoiled, the stainless may lose its shine and the finish may pull threads from the cloth which may be difficult to remove.

NEVER use steel wool to clean stainless steel. Steel wool is usually made from carbon steel and the fragments left behind, as well as scratching the surface, will rust onto the stainless steel surface causing further damage. If a scourer is to be used, use a plastic scourer such as Scotchbrite or a stainless steel wool scourer.

Allegion (Australia) Pty Ltd
Freephone: 1800 098 094
Email: auinfo@allegion.com
www.ausloc.com

Allegion (New Zealand) Limited
Freephone: 0800 477 869
Email: nzinfo@allegion.com
www.allegion.co.nz

